


11-09-311



(D) Montageanleitung

(GB) Assembly instructions

(FR) Notice de montage

(IT) Istruzioni di montaggio

(NL) Handleiding voor de montage

(PL) Instrukcja montażu

(CZ) Montážní návod




(SK) Návod na montáž

(HU) Szerelési útmutató

(RO) Instrucțiuni de montaj

(TR) Montaj talimatı

(RU) Инструкция по монтажу








Service • Dienstverlening • Serwis • Servis • Сервисная служба






Name • Naam • Nazwa • Isim • Название

Nr. • No. • Номер

Typ • Type • Тип • Тип



A	B	C	D	E	F	G	H
							
M6x30	M6x45		M4x14			M4x35	
x14	x6	x14	x2	x2	x2	x2	x1

① 900x355	② 900x355	③ 866x380	④ 700x26	⑤ 700x26
				
x1	x2	x2	x1	x2

1

B




M6x45

x6

H



x1



2


D




M4x14

x2

E



x2



3

A



M6x30

x14

C



x14

H




x1

C*14

A*14

H

80%




4

Ax14

Bx6

100%

H



5

F



x2

G



M4x35

x2

